

# TABLE OF CONTENTS

## **GENERAL DETAILS**

FA2010 - BRIDGE STARTER INSTALLATION

FA2012 - INTERMEDIATE BRIDGE INSTALLATION DETAIL

FA2013 - ENDING BRIDGE INSTALLATION DETAIL


FA2035 - CFR START - FINISH PANEL WIDTH DETAIL

Detail Size (W x H): 4 x 3



### FA2010 - BRIDGE STARTER INSTALLATION

Download the DWG file by clicking here.



### **Detailer Notes:**


1) REQUIRED ON ALL R-Boost™ PROJECTS.

Issued : 10.14.22 (2020.039) CERTIFIED ERECTION DETAILS
Issued By: SLF



#### FA2012 - INTERMEDIATE BRIDGE INSTALLATION DETAIL

Download the DWG file by clicking here.



#### **Detailer Notes:**

1) REQUIRED ON ALL R-Boost™ PROJECTS

: 10.14.22 (2020.039) Issued Issued By: SLF




## **GENERAL DETAILS**

### R-Boost™ ELEVATED INSULATION SYSTEM

#### FA2013 - ENDING BRIDGE INSTALLATION DETAIL

Download the DWG file by clicking here.



## **Detailer Notes:**

1) REQUIRED ON ALL R-Boost™ PROJECTS


Issued : 10.14.22 (2020.039) CERTIFIED ERECTION DETAILS Detail Size (W x H) : 3 x 2

Issued By: SLF



#### FA2035 - CFR START / FINISH PANEL WIDTH DETAIL

Download the DWG file by clicking here.



## START / END CUT PANEL DIMENSION DETAIL

- WHEN FIELD CUTTING OR MITERING ROOF PANELS, NON-ABRASIVE CUTTING TOOLS SUCH AS NIBBLERS OR TIN-SNIPS SHALL BE USED.
- ABRASIVE CUTTING TOOLS SUCH AS MECHANICAL GRINDERS, SAWS, SHEARS OR SCISSORS CAN DAMAGE THE PANEL FINISH AND CREATE EXCESS METAL SHAVINGS THAT CAN CORRODE THE PANELS.
- THE USE OF NON-APPROVED CUTTING DEVICES MAY VOID YOUR FACTORY WARRANTY.

FA2035

#### **Detailer Notes:**

1) THIS DETAIL IS REQUIRED ON EVERY R-Boost™ PROJECT.

Issued : 10.14.22 (2020.039) CERTIFIED ERECTION DETAILS Detail Size (W x H) : 1 x 1

Issued By: SLF